

INTRODUCTION

Please open the box and make sure nothing has been damaged in shipment. If damage is apparent please contact the ikan customer support department at 713-272-8822 or support@ikancorp.com.

Thank you for purchasing the ikan RM4-25 4 panel dedicated rack-mount unit. We know that you will be extremely pleased with it's versatility and ease of use. If you would like more information on our full line of current and up-coming products please visit our website at: www.ikancorp.com, or call us at 713-272-8822.


PACKAGE CHECK LIST

- RM4-25 Dedicated Rack-mount unit
- Captive switchable AC power supply

GETTING STARTED

Checked by _____

1. Remove the RM4-25 and the included AC power supply from the box.
2. After assembling the AC power supply (by plugging in the supplied power cord) carefully screw the threaded power supply plug into the threaded input on the back of the RM4-25. The RM4-25 is powered up by switching on the power switch located on the front right of the unit. When on, the red light located on the front upper right of the RM4-25 indicates the unit has AC power connected but is not switched on. When the RM4-25 is switched on the red light is off.
3. Plug the AC power adaptor into a convenient AC power receptacle. The included power supply is switchable and functions with any input between 100 to 240 volts so, with the appropriate adaptor, will work in most countries, (Check your country's voltage requirements to make certain they match the included AC adaptor).
4. Plug your video source (via a composite male BNC plug) into the BNC female 'Input' of one or more of the four RM4-25 onboard monitors. The RM4-25 has full loop-thru via the 'Output' so the signal can be passed on to another monitor, a video mixer, or a recording deck if desired.
5. When the RM4-25 is rack mounted the unit can be tilted for a more comfortable viewing angle.
6. When desired remove the protective film from the surface of the 4 LCD Panels.
7. For LCD panel adjustment turn the Color, Brightness, or Contrast wheels (located on the front of the RM4-25 under each monitor) until the desired look is achieved.



CONDITIONS OF WARRANTY SERVICE

- Free service for one year from the day of purchase if the problem is caused by manufacturing errors.
- A maintenance service fee plus parts will be charged if the warranty period has expired.

Free Service will not be Provided in the Following Situations:

- Damage caused by abuse or misuse, dismantling, or changes to the product not made by the company. *
- Damage caused by natural disaster, abnormal voltage, and environmental factors etc. *

* Even if the product is still within the warranty period.